

Intel® Network Adapter historical driver and software version numbers

This table is provided to help users determine if the Intel® drivers, firmware, or software they are using is the latest available.

To check your currently loaded driver version you can do the following:

- Windows*: Select your Network Adapter from Device Manager, and then select the Driver Tab.
- Linux*: At a command prompt type: `lspci -nn | grep -i 'Ethernet Controller'`
- Netware*: From Monitor select "LAN/WAN Drivers" option.

10 Gigabit						
Operating System	Bus	Component	Release 13.5	Release 14.0	Release 14.3	Release 14.5
			(Jan. 09)	(Mar. 09)	(July 09)	(Sept. 09)
Windows* 32bit (NDIS 5)	PCI-E	ixe5132.sys	1.6.9.0	1.6.9.0	2.2.30.0	2.3.9.0
Windows* 32bit (NDIS 5)	PCI-X	ixgb325.sys	2.1.18.0a	2.1.18.0a	2.1.18.0a	2.1.18.0a
Windows* 32bit (NDIS 5.1)	PCI-E	ixe5132.sys	1.6.9.0	1.6.9.0	2.2.30.0	2.3.9.0
Windows* 32bit (NDIS 5.1)	PCI-X	ixgb3251.sys	2.1.18.0a	2.1.18.0a	2.1.18.0a	2.1.18.0a
Windows* 32bit (NDIS 6)	PCI-E	ixe6032.sys	1.6.9.0	1.6.9.0	2.2.30.0	2.3.9.0
Windows* 32bit (NDIS 6)	PCI-X	ixg6032.sys	4.1.4.0	4.1.4.0	4.1.4.0	4.1.4.0
Windows* 32bit (NDIS 6)	PCI-E	ixn6032.sys	-	-	2.2.30.0	2.2.30.0
Windows* 32bit (NDIS 6.2)	PCI-E	ixe6232.sys	-	-	-	2.3.10.0
Windows* x64 (NDIS 5.1)	PCI-E	ixe51x64.sys	1.6.9.0	1.6.9.0	2.2.30.0	2.3.9.0
Windows* x64 (NDIS 5.1)	PCI-X	ixg5132e.sys	2.1.18.0a	2.1.18.0a	2.1.18.0a	2.1.18.0a
Windows* x64 (NDIS 6)	PCI-E	ixe60x64.sys	1.6.9.0	1.6.9.0	2.2.30.0	2.3.9.0
Windows* x64 (NDIS 6)	PCI-X	ixg60x64.sys	4.1.4.0	4.1.4.0	4.1.4.0	4.1.4.0
Windows* x64 (NDIS 6)	PCI-E	ixn60x64.sys	-	-	2.2.30.0	2.2.30.0
Windows* x64 (NDIS 6.2)	PCI-E	ixe62x64.sys	-	-	-	2.3.10.0
Windows* 64bit Itanium (NDIS 5.1)	PCI-E	ixe5164.sys	1.6.9.0	1.6.9.0	2.2.30.0	2.3.9.0
Windows* 64bit Itanium (NDIS 5.1)	PCI-X	ixgb6451.sys	2.1.18.0a	2.1.18.0a	2.1.18.0a	2.1.18.0a
Windows* 64bit Itanium (NDIS 6)	PCI-E	ixe6064.sys	1.6.9.0	1.6.9.0	2.2.30.0	2.3.9.0
Windows* 64bit Itanium (NDIS 6)	PCI-X	ixg6064.sys	4.1.4.0	4.1.4.0	4.1.4.0	4.1.4.0
Windows* 64bit Itanium (NDIS 6)	PCI-E	ixn6064.sys	-	-	2.2.30.0	2.2.30.0
Windows* 64bit Itanium (NDIS 6.2)	PCI-E	ixe6264.sys	-	-	-	2.3.10.0

Windows*7 and 2008R2	All	ANS	-	-	9.7.0.8	9.7.0.8
Windows* Vista and 2008	All	ANS	9.5.15.0	9.5.23.0	9.5.26.0	9.5.26.0
Windows* XP and 2003	All	ANS	-	8.6.15.0	8.6.19.0	8.6.19.0
FreeBSD* 7	PCI-E	ixgbe	1.6.4a	1.6.4a	1.8.8	1.9.0
Linux*	PCI-E	ixgbe	1.3.56.5	1.3.56.11	2.34.3	2.0.38.2
Windows* 2003 32/64bit	PCI-E	iSCSIDump.sys	2.1.7.3	2.1.8.3	2.1.10.13	2.1.12.3
Windows* 2003 32/64bit	PCI-E	iSSetup.sys	2.1.7.3	2.1.8.3	2.1.10.13	2.1.12.3

Gigabit

Operating System	Bus	Component	Release 13.5	Release 14.0	Release 14.3	Release 14.5
			(Jan. 09)	(Mar. 09)	(July 09)	(Sept. 09)
Windows NT* 32bit (NDIS 5)	PCI-X	e1000NT5.sys	8.10.3.0	8.10.3.0	8.10.3.0	8.10.3.0
Windows* 32bit (NDIS 5)	PCI-E	e1e5032.sys	9.12.36.0	9.12.36.0	9.12.36.0	9.12.36.0
Windows* 32bit (NDIS 5)	PCI-E	e1e5132.sys	9.12.36.0	9.12.36.0	9.12.36.0	9.12.36.0
Windows* 32bit (NDIS 5)	PCI-E	e1k5032.sys	10.4.19.0	10.4.19.0	10.7.31.0	10.7.31.0
Windows* 32bit (NDIS 5)	PCI-E	e1q5032.sys	10.3.49.4	10.6.15.0	10.6.15.0	11.1.6.0
Windows* 32bit (NDIS 5)	PCI-E	e1y5032.sys	9.52.20.0	9.52.20.0	9.52.25.0	9.52.25.0
Windows* 32bit (NDIS 5)	PCI-X	e1000325.sys	8.10.3.0	8.10.3.0	8.10.3.0	8.10.3.0
Windows* 32bit (NDIS 5.1)	PCI-E	e1k5132.sys	10.4.19.0	10.4.19.0	10.7.31.0	10.7.31.0
Windows* 32bit (NDIS 5.1)	PCI-E	e1q5132.sys	10.3.49.4	10.6.15.0	10.6.15.0	11.1.6.0
Windows* 32bit(NDIS 5.1)	PCI-E	e1y5132.sys	9.52.20.0	9.52.20.0	9.52.25.0	9.52.25.0
Windows* 32bit (NDIS 6)	PCI-E	e1e6032.sys	9.12.36.0	9.12.36.0	9.12.36.0	9.12.36.0
Windows* 32bit (NDIS 6)	PCI-E	e1g6032.sys	8.3.15.0	8.3.15.0	8.3.15.0	8.3.15.0
Windows* 32bit (NDIS 6)	PCI-E	e1k6032.sys	10.4.19.0	10.4.19.0	10.7.31.0	10.7.31.0
Windows* 32bit (NDIS 6)	PCI-E	e1q6032.sys	10.3.49.4	10.6.15.0	10.6.15.0	11.1.6.0
Windows* 32bit (NDIS 6)	PCI-E	e1y6032.sys	9.52.20.0	9.52.20.0	9.52.25.0	9.52.25.0
Windows* 32bit (NDIS 6.2)	PCI-E	e1e6232.sys	-	-	9.13.12.0	9.13.12.0
Windows* 32bit (NDIS 6.2)	PCI-E	e1k6232.sys	-	-	11.0.41.0	11.0.41.0
Windows* 32bit (NDIS 6.2)	PCI-E	e1q6232.sys	-	-	11.0.35.0	11.0.103.0
Windows* 32bit (NDIS 6.2)	PCI-E	e1y6232.sys	-	-	10.0.6.0	10.0.6.0

Windows* x64 (NDIS 5.1)	PCI-E	e1e5132e.sys	9.12.36.0	9.12.36.0	9.12.36.0	9.12.36.0
Windows* x64 (NDIS 5.1)	PCI-E	e1k51x54.sys	10.4.19.0	10.4.19.0	10.7.31.0	10.7.31.0
Windows* x64 (NDIS 5.1)	PCI-E	e1q51x64.sys	10.3.49.4	10.6.15.0	10.6.15.0	11.1.6.0
Windows* x64 (NDIS 6)	PCI-E	e1e6032e.sys	9.12.36.0	9.12.36.0	9.12.36.0	9.12.36.0
Windows* x64 (NDIS 6)	PCI-E	e1g6032e.sys	8.3.15.0	8.3.15.0	8.3.15.0	8.3.15.0
Windows* x64 (NDIS 6)	PCI-E	e1k60x64.sys	10.4.19.0	10.4.19.0	10.4.19.0	10.4.19.0
Windows* x64 (NDIS 6)	PCI-E	e1q60x64.sys	10.3.49.4	10.6.15.0	10.6.15.0	11.1.6.0
Windows* x64 (NDIS 6.2)	PCI-E	e1e62x64.sys	-	-	9.13.12.0	9.13.12.0
Windows* x64 (NDIS 6.2)	PCI-E	e1k62x64.sys	-	-	11.0.41.0	11.0.41.0
Windows* x64 (NDIS 6.2)	PCI-E	e1q62x64.sys	-	-	11.0.35.0	11.0.103.0
Windows* x64 (NDIS 6.2)	PCI-E	e1y62x64.sys	-	-	10.0.6.0	10.0.6.0
Windows* 64bit Itanium (NDIS 5)	PCI	e1000645.sys	8.10.3.0	8.10.3.0	8.10.3.0	8.10.3.0
Windows* 64bit Itanium (NDIS 5.1)	PCI-E	e1e5164.sys	9.12.36.0	9.12.36.0	9.12.36.0	9.12.36.0
Windows* 64bit Itanium (NDIS 5.1)	PCI-E	e1q5164.sys	10.3.49.4	10.6.15.0	10.6.15.0	11.1.6.0
Windows* 64bit Itanium (NDIS 6)	PCI-E	e1e6064.sys	9.12.36.0	9.12.36.0	9.12.36.0	9.12.36.0
Windows* 64bit Itanium (NDIS 6)	PCI-E	e1g6064.sys	8.3.15.0	8.3.15.0	8.3.15.0	8.3.15.0
Windows* 64bit Itanium (NDIS 6)	PCI-E	e1q6064.sys	10.3.49.4	10.6.15.0	10.6.15.0	11.1.6.0
Windows* 64bit Itanium (NDIS 6.2)	PCI-E	e1e6264.sys	-	-	9.13.12.0	9.13.12.0
Windows* 64bit Itanium (NDIS 6.2)	PCI-E	e1k6264.sys	-	-	11.0.41.0	11.0.41.0
Windows* 7 and 2008R2	All	ANS			9.7.0.8	9.7.0.8
Windows* Vista and 2008	All	ANS	9.5.15.0	9.5.23.0	9.5.26.0	9.5.26.0
Windows* XP and 2003	All	ANS	8.6.10.0	8.6.15.0	8.6.19.0	8.6.19.0
FreeBSD* 7	PCI	em	6.9.5b	6.9.8	6.9.12a	6.9.12a
FreeBSD* 7	PCI-E	igb	1.3.2	1.5.2	1.7.3	1.7.3
Linux*	PCI	e1000	8.0.0	8.0.0	8.0.13	8.0.16
Linux*	PCI-E	e1000e	0.5.11.2	0.5.18.3	1.0.2.5	1.0.2.5
Linux*	PCI-E	igb	1.3.8.6	1.3.19.3a	1.3.19.3a	1.3.28.4
DOS	All	e1000.dos	5.29	5.31	5.37	5.37
DOS ODI	All	e1000odi.com	4.28	4.31	4.37	4.37
Netware*	PCI-E	e1000e.lan	10.48	10.53	10.53	10.53
Netware*	PCI-E	e1000q.lan	11.24	11.31	11.31	11.31
UnixWare* 7	PCI-X	e1008g.pkg	11.0.5	11.0.5	11.0.5	11.0.5

Windows* 2003 32/64bit	PCI-E	iSCSIDump.sys	2.1.7.3	2.1.8.3	2.1.10.13	2.1.12.3
Windows* 2003 32/64bit	PCI-E	iSSetup.sys	2.1.7.3	2.1.8.3	2.1.10.13	2.1.12.3
10/100 Mb						
Operating System	Bus	Component	Release 13.5	Release 14.0	Release 14.3	Release 14.5
			(Jan. 09)	(Mar. 09)	(July 09)	(Sept. 09)
Windows* 32bit (NDIS 5)	PCI	e100b325.sys	8.0.47.0	8.0.47.0	8.0.47.0	8.0.47.0
Windows* 32bit (NDIS 5)	PCI	e100a325.sys	8.0.47.0	8.0.47.0	8.0.47.0	8.0.47.0
Windows* 32bit (NDIS 5)	PCI	e100ant5.sys	8.0.47.0	8.0.47.0	8.0.47.0	8.0.47.0
Windows* 32bit (NDIS 5.1)	PCI	fe5132.sys			9.0.12.0	9.0.12.0
Windows* 32bit (NDIS 6.2)	PCI	fe6232.sys			9.0.12.0	9.0.12.0
Windows* x64 (NDIS 5.1)	PCI-E	eFE5b32e.sys	9.12.30.0	9.12.30.0	9.12.30.0	9.12.30.0
Windows* x64 (NDIS 5.1)	PCI	fei51x64.sys			9.0.12.0	9.0.12.0
Windows* x64 (NDIS 6.2)	PCI	fei62x64.sys			9.0.12.0	9.0.12.0
Windows* 64bit Itanium (NDIS 5)	PCI	e100a645.sys	8.0.47.0	8.0.47.0	8.0.47.0	8.0.47.0
Windows* 64bit Itanium (NDIS 5)	PCI	e100b645.sys	8.0.47.0	8.0.47.0	8.0.47.0	8.0.47.0
Windows*7 and 2008R2	All	ANS	-	-	9.7.0.8	9.7.0.8
Windows Vista*	All	ANS	9.5.15.0	9.5.23.0	9.5.26.0	9.5.26.0
Windows* XP and 2003 32/64bit	All	ANS	8.6.10.0	8.6.15.0	8.6.19.0	8.6.19.0
DOS	PCI	e100b.dos	4.57a	4.57a	4.58	4.58
DOS ODI	PCI	e100bodi.com	4.13	4.13	4.14	4.14
Utilities						
Operating System	Bus	Component	Release 13.5	Release 14.0	Release 14.3	Release 14.5
			(Jan. 09)	(Mar. 09)	(July 09)	(Sept. 09)
Windows* XP to 2008		PROSet			14.3.0.0	14.5.1.0
Windows* 7 to 2008R2		PROSet			14.3.100. 0	14.5.1.0
Windows 2003* 32/64bit	PCI-E	iSCSIBoot	2.1.7.3	2.1.8.3	2.1.10.13	2.1.12.3
Linux*	PCI-E	iSCSIBoot	R23	R23	R23	R23
DOS	PCI-E	iSCSIUtl.exe	2.2.96.1	2.3.17	2.3.45	2.3.62
Windows* 32bit	PCI-E	Adaptchk.exe	13.5	14.0	14.3	14.4
Windows* XP and 2003	PCI-E	IOAT Check Utility	13.5.3.0	14.0.0.2	14.3.0.0	14.2.102.0
BootROM	All	PXE BootROM Image	4.11.4.10	4.11.7.3	4.12.1.9	4.12.2.15
DOS	All	IBAUtl.exe	4.11.4.10	4.11.7.3	4.12.1.9	4.12.2.15
SNMP	All	SNMP MIB	1.4.4.6	1.4.4.6	1.4.4.6	1.4.4.6

*Other names and brands may be claimed as the property of others.
Microsoft, Windows, and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.