

- IPMI -

Platform Management FRU Information
Storage Definition
v1.0

Document Revision 1.1

September 27, 1999

Intel Hewlett-Packard NEC Dell

Revision History

| Date | Rev | Modifications |
|---------|-----|--|
| 9/16/98 | 1.0 | Initial release. |
| 9/27/99 | 1.1 | Updates to cover errata and clarifications. Added new compatibility MultiRecord types to support distributed power bay applications. |

Copyright © 1998, 1999 Intel Corporation, Hewlett-Packard Company, NEC Corporation, Dell Computer Corporation, All rights reserved.

INTELLECTUAL PROPERTY DISCLAIMER

THIS SPECIFICATION IS PROVIDED "AS IS" WITH NO WARRANTIES WHATSOEVER INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION, OR SAMPLE.

NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED OR INTENDED HEREBY.

INTEL, HEWLETT-PACKARD, NEC, AND DELL DISCLAIMS ALL LIABILITY, INCLUDING LIABILITY FOR INFRINGEMENT OF PROPRIETARY RIGHTS, RELATING TO IMPLEMENTATION OF INFORMATION IN THIS SPECIFICATION. INTEL, HEWLETT-PACKARD, NEC, AND DELL, DOES NOT WARRANT OR REPRESENT THAT SUCH IMPLEMENTATION(S) WILL NOT INFRINGE SUCH RIGHTS.

I²C is a trademark of Phillips Semiconductors. All other product names are trademarks, registered trademarks, or servicemarks of their respective owners.

I²C is a two-wire communications bus/protocol developed by Philips. IPMB is a subset of the I²C bus/protocol and was developed by Intel. Implementations of the I²C bus/protocol or the IPMB bus/protocol may require licenses from various entities, including Philips Electronics N.V. and North American Philips Corporation.

Intel, Hewlett-Packard, NEC, and Dell retain the right to make changes to this document at any time, without notice. Intel, Hewlett-Packard, NEC, and Dell make no warranty for the use of this document and assume no responsibility for any error which may appear in the document nor does it make a commitment to update the information contained herein.

Table of Contents

| | |
|---|-----------|
| 1. Introduction..... | 1 |
| 2. Reference Documents..... | 2 |
| 3. Accessing FRU Inventory Devices..... | 2 |
| 4. Accessing FRU Inventory Device Data..... | 2 |
| 5. More on Predefined and Custom Fields..... | 3 |
| 6. Suggested Storage Organization..... | 4 |
| 7. Changing Area Allocations..... | 4 |
| 8. Common Header Format..... | 5 |
| 9. Internal Use Area Format..... | 5 |
| 10. Chassis Info Area Format..... | 6 |
| 11. Board Info Area Format..... | 7 |
| 12. Product Info Area Format..... | 8 |
| 13. TYPE/LENGTH BYTE FORMAT..... | 9 |
| 13.1 BCD PLUS definition:..... | 9 |
| 13.2 6-bit ASCII definition..... | 10 |
| 13.3 6-bit ASCII Packing Example..... | 10 |
| 14. System Enclosure and Chassis Types..... | 11 |
| 15. Language Codes..... | 12 |
| 16. MultiRecord Area..... | 13 |
| 16.1 Record Header..... | 13 |
| 16.2 Record Header Fields..... | 13 |
| 16.2.1 Record Type Identification..... | 13 |
| 16.2.2 End of List..... | 14 |
| 16.2.3 Record Format Version..... | 14 |
| 16.2.4 Record Length..... | 14 |
| 16.2.5 Record Checksum..... | 14 |
| 16.2.6 Header Checksum..... | 14 |

| | |
|---|-----------|
| 17. FRU Information Layout..... | 15 |
| 18. Record Field Definitions | 16 |
| 18.1 Power Supply Information (Record Type 0x00) | 16 |
| 18.1.1 Overall Capacity in Watts | 16 |
| 18.1.2 Peak VA | 17 |
| 18.1.3 Inrush | 17 |
| 18.1.4 Inrush interval | 17 |
| 18.1.5 Low end Input voltage range 1 | 17 |
| 18.1.6 High end Input voltage range 1 | 17 |
| 18.1.7 Low end Input voltage range 2..... | 17 |
| 18.1.8 High end Input voltage range 2 | 17 |
| 18.1.9 Low end input frequency range | 17 |
| 18.1.10 High end input frequency range | 17 |
| 18.1.11 A/C dropout tolerance | 17 |
| 18.1.12 Binary flags | 17 |
| 18.1.12.1 Tachometer pulses per rotation/Predictive fail polarity | 17 |
| 18.1.12.2 Other Binary flags..... | 18 |
| 18.1.13 Peak Wattage..... | 18 |
| 18.1.14 Combined Wattage..... | 18 |
| 18.1.15 Predictive fail tachometer lower threshold | 18 |
| 18.2 DC Output (Record Type 0x01)..... | 19 |
| 18.2.1 Output Information..... | 19 |
| 18.2.2 Nominal voltage | 19 |
| 18.2.3 Maximum negative voltage deviation | 20 |
| 18.2.4 Maximum positive voltage deviation..... | 20 |
| 18.2.5 Ripple and Noise pk-pk, 10Hz to 30MHz | 20 |
| 18.2.6 Minimum current draw..... | 20 |
| 18.2.7 Maximum current draw | 20 |
| 18.3 DC Load (Record Type 0x02)..... | 20 |
| 18.3.1 Output Information..... | 20 |
| 18.3.2 Nominal voltage | 20 |
| 18.3.3 Spec'd minimum voltage | 20 |
| 18.3.4 Spec'd maximum voltage | 21 |
| 18.3.5 Ripple and Noise pk-pk 10Hz to 30MHz | 21 |
| 18.3.6 Minimum current load | 21 |
| 18.3.7 Maximum current load | 21 |
| 18.4 Management Access Record (Record Type 0x03)..... | 21 |
| 18.4.1 Example..... | 22 |
| 18.5 Base Compatibility Record | 24 |

| | |
|---|----|
| 18.6 Extended Compatibility Record..... | 25 |
| 18.6.1 Code Range Mask Fields Usage Example | 26 |
| 18.7 OEM Record..... | 26 |

1. Introduction

This document defines and describes the common format and use of the FRU (Field Replaceable Unit) Information storage in platforms using the Intelligent Platform Management Interface.

The FRU Information is used to primarily to provide ‘inventory’ information about the boards that the FRU Information Device is located on. It is a goal that all major field replaceable units (FRUs) have an EEPROM or FRU Information Device from which, at a minimum, the part number or version number can be read through software. It is also a goal that the FRUs serial number be software readable.

The stored information follows that defined in the ‘DMI Vital Product Data Specification Rev. 2.2’. That document specifies the type and format of similar information that would be stored in the baseboard’s BIOS FLASH during manufacture.

The format divides the FRU Information Device (or EEPROM) into six different areas:

- Common Header** The Common Header is mandatory for all FRU Information Device implementations. It holds version information for the overall information format specification and offsets to the other information areas. The other areas may or may not be present based on the application of the device. An area is specified as ‘Null’ or ‘not present’ when the Common Header has a value of 00h for the starting offset for that area.
- Internal Use Area** This area provides private, implementation-specific information storage for other devices that exist on the same FRU as the FRU Information Device. The Internal Use Area is usually used to provide private non-volatile storage for a management controller.
- Chassis Info Area** This area is used to hold Serial Number, Part Number, and other information about the system chassis. A system can have multiple FRU Information Devices within a chassis, but only one device should provide the Chassis Info Area. Thus, this area will typically be absent from most FRU Information Devices. Ideally this information is in a FRU device that is part of a board that is associated with the chassis, such as a front panel or power distribution board. But many systems, particularly low-end systems, do not incorporate such locations. Therefore, it is common to find the Chassis Info Area included in the FRU information for the baseboard.
- Board Info Area** This area provides Serial Number, Part Number, and other information about the board that the FRU Information Device is located on.
- Product Info Area** This area is present if the FRU itself is a separate product. This is typically seen when the FRU is an add-in card. When this area is provided in the FRU Information Device that contains the Chassis Info Area, the product info is for the overall system, as initially manufactured.
- MultiRecord Info Area** The MultiRecord Info Area provides a region that holds one or more records where the type and format of the information is specified in the individual headers for the records. This differs from the other information areas, where the type and format of the information are implied by which offset is used in the Common Header. The MultiRecord Info Area provides a mechanism for extending the FRU Information Specification to cover new information types without impacting the existing area definitions.

2. Reference Documents

The following documents are companion and supporting specifications for this document:

- [1] *Intelligent Platform Management Interface Specification, Version 1.0*, © 1998, 1999 Intel Corporation, Hewlett-Packard Company, NEC Corporation, Dell Computer Corporation.
- [2] *Network PC System Design Guidelines, Version 1.0b*, ©1997 Compaq Computer Corporation, Dell Computer Corporation, Hewlett-Packard Company, Intel Corporation, and Microsoft Corporation. Appendix K is referenced as providing the format specification for the GUID (Globally Unique Identifier) referenced in this specification.

3. Accessing FRU Inventory Devices

Storage for FRU Inventory Devices can be provided by storage devices that are located directly on the Intelligent Management Bus, or on a 'Private Management Bus'. In this case, the device is typically accessed directly using whatever low-level access interface the device provides.

Because system software needs to know the particular details of how to access the storage device, only a limited number of types of storage devices are supported for direct access. Presently, the supported devices are SEEPROMs that use a '24C02'-compatible interface, and SEEPROMs that are compatible with the Dallas Semiconductor DS1624 Temperature Sensor/SEEPROM interface.

Alternately, a management controller can be used to provide the interface to the FRU Inventory Device. The management controller provides *Read/Write FRU Inventory Data* commands for accessing the non-volatile storage contents via the controller's messaging interface. This is the preferred implementation. The approach provides additional data integrity checking and error handling that are not available when a non-volatile storage device is accessed directly. It also isolates software from the implementation of the non-volatile storage hardware. That is, software uses the same Read/Write FRU Inventory Data commands to the management controller regardless of the type of device used to provide the storage.

During manufacture, initial programming of the devices can be accomplished by other methods, as best suit manufacturing requirements. For example, in some instances a device may be directly accessed by direct connection to its pins via a circuit test fixture.

4. Accessing FRU Inventory Device Data

The Common Header area is the starting point for accessing FRU information data. The Common Header area always starts at offset 00h. The Common Header is present for all FRU Information Devices in the system. The data in this header provides the offsets to the other information areas in the device. A checksum is included to allow the integrity of the header data to be verified.

The Chassis Info, Board Info, and Product Info areas each contain a number of variable length fields. Each of these fields is preceded by a type/length byte that indicates the length of the field and the type of encoding that is used for the field. The leading fields in each area serve predefined functions. These fields can be followed by 'custom' fields that are defined by manufacturing or by the OEM. The same variable length field format is used within records in the MultiRecord Area.

An application that accesses the information starts by verifying that the format version information for the FRU Information Device is a version that the application supports. It does this by extracting the format version information from Common Header area. Next, the application extracts the starting offset for the desired area from the Common Header. The application then accesses the 'header' information specified

at the beginning of the area. If the area format version is correct, the application can proceed an access the data. (Note for the MultiRecord area, the Common Header offset points both the start of the area and to the first *Record* in the MultiRecord area.)

Since the fields within an area (or Record) can be variable or fixed length, the application must ‘walk’ the fields sequentially. The application traverses all fields by walking individual fields until the ‘end-of-fields’ type/length byte (value C1h) is encountered. (*Note: Only pre-defined fields are allowed to be fixed length without type/length bytes. All custom fields are specified as variable length fields with type/length bytes.*)

Each area/record starts with a fixed number of pre-defined fields. This is followed by a variable number of optional custom fields. If a field is not used, a ‘NULL’ or ‘Empty’ version of the field is used as a placeholder. Thus, an application can rely on the Nth field as always having the same meaning. (*Note: this is guaranteed for pre-defined fields only.*)

An application could present predefined fields with labels according to their function and formatted according to the ‘type’ specified in the type/length field. The application could present custom fields with a generic label (e.g. ‘Custom Field 1’) followed by the field data formatted according to the ‘type’ specified in the type/length field (e.g. Hex, ASCII, Binary).

Prior to using any FRU Information Data, an applications should validate the checksum for the area or record.

5. More on Predefined and Custom Fields

If an area is present (as indicated by a non-zero offset in the Common Header) the predefined fields for that area must also be present. The predefined fields can be made ‘Null’, however. This is done by setting the type/length byte to “xx000000” to indicate that the field has no data. All pre-defined fields must be present regardless of whether they are ‘Null’ or not. Custom fields must always be preceded with a type/length byte. The ‘end-of-fields’ byte and area checksum are also required.

6. Suggested Storage Organization

The following tables show the *suggested* allocation of storage space. Since the fields are variable lengths, different allocation can be used while still meeting this specification. It is recommended that this distribution be used unless the particular implementation requires field size adjustments (See section on *Changing Area Allocations*, below).

If the Chassis Info Area is not utilized, it is recommended that the Chassis Info Area space either be allocated to the Internal Use Area space, or be left unused. Fields in the board and product info areas are preceded with a type/length byte (with the exception of the version and manufacturing date fields). This indicates how long the field is, and how it is encoded (binary, BCD, 6-bit ASCII, 8-bit ASCII).

SUGGESTED 2K BIT EEPROM ORGANIZATION

| Size | Name | Description |
|-----------|-------------------|---|
| 8 bytes | Common Header | Offsets to other areas |
| 72 bytes | Internal Use Area | This area is reserved for management firmware and baseboard use. |
| 32 bytes | Chassis Info Area | Chassis info area. This area holds information about the chassis. This area should be included in only one FRU device in the system, and should be absent from other FRU devices (as indicated by a 0 offset for this area in the common header). If this area is not used, the space may be re-allocated to other areas. |
| 64 bytes | Board Info Area | Board info area (52 available) |
| 80 bytes* | Product Info Area | product info, OEM - customer definable (70 available) |

NOTE: The format specifies these areas as variable length. Area sizes may be adjusted to reflect actual space requirements.

* = MINIMUM Recommendation. The goal is to always provide at least 80 bytes for this area when 2K bit or larger EEPROMs are used.

7. Changing Area Allocations

The various areas (other than the Common Header) are specified as variable length regions. If necessary, a FRU Information Device management application can change the allocations from their initial values (assuming that it moves all fields and updates the Common Header and other offsets appropriately).

The main exception to this is that an application should never change the location or size of the Internal Use Area, unless that is explicitly required as part of an update procedure for the device that 'owns' the Internal Use Area.

8. Common Header Format

COMMON HEADER

| field length | field |
|--------------|--|
| 1* | Common Header Format Version 7:4 - reserved, write as 0000b 3:0 - format version number = 1h for this specification. |
| 1* | Internal Use Area Starting Offset (in multiples of 8 bytes). 00h indicates that this area is not present. |
| 1* | Chassis Info Area Starting Offset (in multiples of 8 bytes). 00h indicates that this area is not present. |
| 1* | Board Area Starting Offset (in multiples of 8 bytes). 00h indicates that this area is not present. |
| 1* | Product Info Area Starting Offset (in multiples of 8 bytes). 00h indicates that this area is not present. |
| 1* | MultiRecord Area Starting Offset (in multiples of 8 bytes). 00h indicates that this area is not present. |
| 1* | PAD, write as 00h |
| 1* | Common Header Checksum (zero checksum) |

* = These fields are MANDATORY

9. Internal Use Area Format

INTERNAL USE AREA (Baseboard Chassis ID definition only)

| field length | field |
|--------------|---|
| 1* | Internal Use Format Version 7:4 - reserved, write as 0000b 3:0 - format version number = 1h for this specification. |
| xx | Internal use data - defined and formatted as needed for management controller or other device that owns/uses this area. |

* = These fields are MANDATORY

10. Chassis Info Area Format

CHASSIS INFO AREA

| field length | field |
|--------------|--|
| 1 | Chassis Info Area Format Version 7:4 - reserved, write as 0000b 3:0 - format version number = 1h for this specification. |
| 1 | Chassis Info Area Length (in multiples of 8 bytes) |
| 1 | Chassis Type (enumeration) |
| 1 | Chassis Part Number type/length |
| N | Chassis Part Number bytes |
| 1 | Chassis Serial Number type/length* |
| M | Chassis Serial Number bytes* |
| xx | Custom Chassis Info fields, if any. Each fields must be preceded with type/length byte. |
| 1 | C1h (type/length byte encoded to indicate no more info fields). |
| Y | 00h - any remaining unused space |
| 1 | Chassis Info Checksum (zero checksum) |

* These areas are always encoded as if the Language Code were English.

11. Board Info Area Format

BOARD INFO AREA

| field length | field |
|--------------|--|
| 1 | Board Area Format Version 7:4 - reserved, write as 0000b 3:0 - format version number = 1h for this specification. |
| 1 | Board Area Length (in multiples of 8 bytes) |
| 1 | Language Code (See section 15) |
| 3 | Mfg. Date / Time Number of minutes from 0:00 hrs 1/1/96. LSbyte first (little endian) |
| 1 | Board Manufacturer type/length byte |
| P | Board Manufacturer bytes |
| 1 | Board Product Name type/length byte |
| Q | Board Product Name bytes |
| 1 | Board Serial Number type/length byte* |
| N | Board Serial Number bytes* |
| 1 | Board Part Number type/length byte |
| M | Board Part Number bytes |
| 1 | FRU File ID type/length byte* |
| R | FRU File ID bytes* The FRU File version field is a pre-defined field provided as a manufacturing aid for verifying the file that was used during manufacture or field update to load the FRU information. The content is manufacturer-specific. This field is also provided in the Product Info area. Either or both fields may be 'null'. |
| xx | Additional custom Mfg. Info fields. Defined by manufacturing. Each field must be preceded by a type/length byte |
| 1 | C1h (type/length byte encoded to indicate no more info fields). |
| Y | 00h - any remaining unused space |
| 1 | Board Area Checksum (zero checksum) |

* These areas are always encoded as if the Language Code were English.

12. Product Info Area Format

PRODUCT INFO AREA

| field length | field |
|--------------|--|
| 1 | Product Area Format Version 7:4 - reserved, write as 0000b 3:0 - format version number = 1h for this specification |
| 1 | Product Area Length (in multiples of 8 bytes) |
| 1 | Language Code (See section 15) |
| 1 | Manufacturer Name type/length byte |
| N | Manufacturer Name bytes |
| 1 | Product Name type/length byte |
| M | Product Name bytes |
| 1 | Product Part/Model Number type/length byte |
| O | Product Part/Model Number bytes |
| 1 | Product Version type/length byte |
| R | Product Version bytes |
| 1 | Product Serial Number type/length byte* |
| P | Product Serial Number bytes* |
| 1 | Asset Tag type/length byte |
| Q | Asset Tag |
| 1 | FRU File ID type/length byte |
| R | FRU File ID bytes. The FRU File version field is a pre-defined field provided as a manufacturing aid for verifying the file that was used during manufacture or field update to load the FRU information. The content is manufacturer-specific. This field is also provided in the Board Info area. Either or both fields may be 'null'. |
| xx | Custom product info area fields, if any (must be preceded with type/length byte) |
| 1 | C1h (type/length byte encoded to indicate no more info fields). |
| Y | 00h - any remaining unused space |
| 1 | Product Info Area Checksum (zero checksum) |

* These fields are always encoded as if the Language Code were English. I.e. if the type/length code bits 7:6=11b the serial number will always be interpreted as ASCII+Latin 1, not UNICODE.

13. TYPE/LENGTH BYTE FORMAT

The following presents the specification of the type/length byte.

7:6 - type code

- 00 - binary or unspecified
- 01 - BCD plus (see below)
- 10 - 6-bit ASCII, packed (overrides Language Codes)
- 11 - Interpretation depends on Language Codes. 11b indicates 8-bit ASCII + Latin 1 if the Language Code is English for the area or record containing the field, or 2-byte UNICODE (least significant byte first) if the Language Code is not English. At least two bytes of data must be present when this type is used. Therefore, the length (number of data bytes) will always be >1 if data is present, 0 if data is not present.

5:0 - number of data bytes.

000000 indicates that the field is empty. When the type code is 11b, a length of 000001 indicates 'end of fields'. I.e. Type/Length = C1h indicates 'end of fields'.

"ASCII+LATIN1" is derived from the first 256 characters of Unicode 2.0. The first 256 codes of Unicode follow ISO 646 (ASCII) and ISO 8859/1 (Latin 1). The Unicode "C0 Controls and Basic Latin" set defines the first 128 8-bit characters (00h-7Fh) and the "C1 Controls and Latin-1 Supplement" defines the second 128 (80h-FFh).

"6-bit ASCII" is the 64 characters starting from character 20h (space) from the ASCII+LATIN1 set. So 6-bit ASCII value 000000b maps to 20h (space), 000001b maps to 21h (!), etc. Packed 6-bit ASCII takes the 6-bit characters and packs them 4 characters to every 3 bytes, with the first character in the least significant 6-bits of the first byte. A table of 6-bit ASCII codes and an example of packed 6-bit ASCII characters is included later in this section.

13.1 BCD PLUS definition:

0h - 9h = digits 0 through 9
Ah = space
Bh = dash '-'
Ch = period '.'
Dh = reserved
Eh = reserved
Fh = reserved

13.2 6-bit ASCII definition

| | | | | | | | |
|---|----|----|---|----|---|----|---|
| 0 | sp | 10 | 0 | 20 | @ | 30 | P |
| 1 | ! | 11 | 1 | 21 | A | 31 | Q |
| 2 | " | 12 | 2 | 22 | B | 32 | R |
| 3 | # | 13 | 3 | 23 | C | 33 | S |
| 4 | \$ | 14 | 4 | 24 | D | 34 | T |
| 5 | % | 15 | 5 | 25 | E | 35 | U |
| 6 | & | 16 | 6 | 26 | F | 36 | V |
| 7 | ' | 17 | 7 | 27 | G | 37 | W |
| 8 | (| 18 | 8 | 28 | H | 38 | X |
| 9 |) | 19 | 9 | 29 | I | 39 | Y |
| A | * | 1A | : | 2A | J | 3A | Z |
| B | + | 1B | ; | 2B | K | 3B | [|
| C | , | 1C | < | 2C | L | 3C | \ |
| D | - | 1D | = | 2D | M | 3D |] |
| E | . | 1E | > | 2E | N | 3E | ^ |
| F | / | 1F | ? | 2F | O | 3F | _ |

13.3 6-bit ASCII Packing Example

"IPMI" encoded in 6-bit ASCII is:

I = 29h (101001b)

P = 30h (110000b)

M = 2Dh (101101b)

I = 29h (101001b)

Which gets packed into bytes as follows:

| | | | | | | | | | |
|--------|---|---|---|---|---|---|---|---|-----|
| bit | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | hex |
| byte 1 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 1 | 29h |
| byte 2 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 0 | DCh |
| byte 3 | 1 | 0 | 1 | 0 | 0 | 1 | 1 | 0 | A6h |

14. System Enclosure and Chassis Types

The following table presents the enumeration values for the chassis type field in the chassis info area. This is based on *System Management BIOS Specification, Version 2.3*, (©1998, American Megatrends, Inc., Award Software International, Inc., Dell Computer Corporation, Intel Corporation, Phoenix Technologies Ltd., SystemSoft Corporation).

| Byte Value | Meaning |
|------------|-----------------------|
| 01h | Other |
| 02h | Unknown |
| 03h | Desktop |
| 04h | Low Profile Desktop |
| 05h | Pizza Box |
| 06h | Mini Tower |
| 07h | Tower |
| 08h | Portable |
| 09h | LapTop |
| 0Ah | Notebook |
| 0Bh | Hand Held |
| 0Ch | Docking Station |
| 0Dh | All in One |
| 0Eh | Sub Notebook |
| 0Fh | Space-saving |
| 10h | Lunch Box |
| 11h | Main Server Chassis |
| 12h | Expansion Chassis |
| 13h | SubChassis |
| 14h | Bus Expansion Chassis |
| 15h | Peripheral Chassis |
| 16h | RAID Chassis |
| 17h | Rack Mount Chassis |

15. Language Codes

The following table should be used when interpreting the Language Code fields. The index number (1-136) is stored in the Language Code field. Any language code other than English indicates that the string data is encoded as Unicode when bits 7:6 of the Type/Length code = 11b.

| | | | | | |
|-----|----|-----------------|------|----|------------------|
| 0. | en | English* | | | |
| 1. | aa | Afar | 51. | it | Italian |
| 2. | ab | Abkhazian | 52. | iw | Hebrew |
| 3. | af | Afrikaans | 53. | ja | Japanese |
| 4. | am | Amharic | 54. | ji | Yiddish |
| 5. | ar | Arabic | 55. | jw | Javanese |
| 6. | as | Assamese | 56. | ka | Georgian |
| 7. | ay | Aymara | 57. | kk | Kazakh |
| 8. | az | Azerbaijani | 58. | kl | Greenlandic |
| 9. | ba | Bashkir | 59. | km | Cambodian |
| 10. | be | Byelorussian | 60. | kn | Kannada |
| 11. | bg | Bulgarian | 61. | ko | Korean |
| 12. | bh | Bihari | 62. | ks | Kashmiri |
| 13. | bi | Bislama | 63. | ku | Kurdish |
| 14. | bn | Bengali; Bangla | 64. | ky | Kirghiz |
| 15. | bo | Tibetan | 65. | la | Latin |
| 16. | br | Breton | 66. | ln | Lingala |
| 17. | ca | Catalan | 67. | lo | Laothian |
| 18. | co | Corsican | 68. | lt | Lithuanian |
| 19. | cs | Czech | 69. | lv | Latvian, Lettish |
| 20. | cy | Welsh | 70. | mg | Malagasy |
| 21. | da | danish | 71. | mi | Maori |
| 22. | de | german | 72. | mk | Macedonian |
| 23. | dz | Bhutani | 73. | ml | Malayalam |
| 24. | el | Greek | 74. | mn | Mongolian |
| 25. | en | English | 75. | mo | Moldavian |
| 26. | eo | Esperanto | 76. | mr | Marathi |
| 27. | es | Spanish | 77. | ms | Malay |
| 28. | et | Estonian | 78. | mt | Maltese |
| 29. | eu | Basque | 79. | my | Burmese |
| 30. | fa | Persian | 80. | na | Nauru |
| 31. | fi | Finnish | 81. | ne | Nepali |
| 32. | fj | Fiji | 82. | nl | Dutch |
| 33. | fo | Faeroese | 83. | no | Norwegian |
| 34. | fr | French | 84. | oc | Occitan |
| 35. | fy | Frisian | 85. | om | (Afan) Oromo |
| 36. | ga | Irish | 86. | or | Oriya |
| 37. | gd | Scots Gaelic | 87. | pa | Punjabi |
| 38. | gl | Galician | 88. | pl | Polish |
| 39. | gn | Guarani | 89. | ps | Pashto, Pushto |
| 40. | gu | Gujarati | 90. | pt | Portuguese |
| 41. | ha | Hausa | 91. | qu | Quechua |
| 42. | hi | Hindi | 92. | rm | Rhaeto-Romance |
| 43. | hr | Croatian | 93. | rn | Kirundi |
| 44. | hu | Hungarian | 94. | ro | Romanian |
| 45. | hy | Armenian | 95. | ru | Russian |
| 46. | ia | Interlingua | 96. | rw | Kinyarwanda |
| 47. | ie | Interlingue | 97. | sa | Sanskrit |
| 48. | ik | Inupiak | 98. | sd | Sindhi |
| 49. | in | Indonesian | 99. | sg | Sangro |
| 50. | is | Icelandic | 100. | sh | Serbo-Croatian |
| | | | 101. | si | Singhalese |
| | | | 102. | sk | Slovak |
| | | | 103. | sl | Slovenian |
| | | | 104. | sm | Samoan |
| | | | 105. | sn | Shona |
| | | | 106. | so | Somali |
| | | | 107. | sq | Albanian |
| | | | 108. | sr | Serbian |
| | | | 109. | ss | Siswati |
| | | | 110. | st | Sesotho |
| | | | 111. | su | Sudanese |
| | | | 112. | sv | Swedish |
| | | | 113. | sw | Swahili |
| | | | 114. | ta | Tamil |
| | | | 115. | te | Tegulu |
| | | | 116. | tg | Tajik |
| | | | 117. | th | Thai |
| | | | 118. | ti | Tigrinya |
| | | | 119. | tk | Turkmen |
| | | | 120. | tl | Tagalog |
| | | | 121. | tn | Setswana |
| | | | 122. | to | Tonga |
| | | | 123. | tr | Turkish |
| | | | 124. | ts | Tsonga |
| | | | 125. | tt | Tatar |
| | | | 126. | tw | Twi |
| | | | 127. | uk | Ukrainian |
| | | | 128. | ur | Urdu |
| | | | 129. | uz | Uzbek |
| | | | 130. | vi | Vietnamese |
| | | | 131. | vo | Volapuk |
| | | | 132. | wo | Wolof |
| | | | 133. | xh | Xhosa |
| | | | 134. | yo | Yoruba |
| | | | 135. | zh | Chinese |
| | | | 136. | zu | Zulu |

* English is index 0 and 25. Index 0 allows earlier revisions of the FRU format EEPROM to be supported.

16. MultiRecord Area

The MultiRecord Area Starting Offset field in the Common Header points to the start of the first record in the ‘MultiRecord’ area. Each record in this area begins with a pre-defined header as specified in the following table. This header contains a ‘Type’ field that identifies what information is contained in the record.

16.1 Record Header

The Record Header also contains offset information needed to find any additional following records, if any, in a sequential list manner. The Record Header has the following format.

| field length | field |
|--------------|--|
| 1 | Record Type ID |
| 1 | 7:7 – End of list 6:4 – Reserved, write as 000b 3:0 – Record Format version (=2h unless otherwise specified) |
| 1 | Record Length |
| 1 | Record Checksum (zero checksum) |
| 1 | Header Checksum (zero checksum) |

Any data associated with the header will follow the last field of the header.

16.2 Record Header Fields

16.2.1 Record Type Identification

This unsigned byte is used to identify the information contained in the record. The following table shows the currently defined record types.

| ID | Record Type | Section |
|-----------|-------------------------------|---------|
| 0x00 | Power Supply Information | 18.1 |
| 0x01 | DC Output | 18.2 |
| 0x02 | DC Load | 18.3 |
| 0x03 | Management Access Record | 18.4 |
| 0x04 | Base Compatibility Record | 0 |
| 0x05 | Extended Compatibility Record | 18.6 |
| 0x06-0xBF | Reserved | - |
| 0xC0-0xFF | OEM Record Types | 18.7 |

See section 18, *Record Field Definitions*, for detailed information on these record types.

16.2.2 End of List

This bit indicates if this record is the last record in the MultiRecord area. If this bit is zero, it indicates that one or more records follow.

16.2.3 Record Format Version

The area version format is stored in the lower nibble of the second byte. This field is used to identify the revision level of information stored in this area. This number will start at zero for each new area. If changes need to be made to the record, e.g. fields added/removed, the version number will be increased to reflect the change.

Unless otherwise specified, the record format version for all record types shall be **02h** for this specification. *Including OEM Record Types*. The latter provision is to provide for standardized data fields that precede the OEM specific data within the OEM Record.

16.2.4 Record Length

This unsigned byte indicates the number of bytes of data in the record. This byte can also be used to find the next area in the list. If the “End of List” bit is zero, the length can be added the starting offset of the current Record Data to get the offset of the next Record Header. This field allows for 0 to 255 bytes of data for each record.

16.2.5 Record Checksum

This unsigned byte can be used to calculate a zero checksum for the data area following the header. I.e. the modulo 256 sum of the record data bytes plus the checksum byte equals zero.

16.2.6 Header Checksum

This unsigned byte is used to give the generic header a zero checksum. I.e. the modulo 256 sum of the preceding bytes (starting with the first byte of the header) plus the checksum byte equals zero.

17. FRU Information Layout

The following shows the layout of a FRU Information Device, including the positioning of Records in the MultiRecord area. FRU Information areas always appear in this order. Note that records in the MultiRecord are not required appear in any order based on Record Type.

FRU Information Layout

| Area | | Comments |
|-------------------|----------|-----------|
| Common Header | | Mandatory |
| Internal Use Area | | Optional |
| Chassis Info Area | | Optional |
| Board Info Area | | Optional |
| Product Info Area | | Optional |
| MultiRecord Area | Record 1 | Optional |
| | Record 2 | Optional |
| | ... | ... |
| | Record X | Optional |

The following example shows a FRU Information Device with a MultiRecord Area, but no Internal Use, Chassis Info, Board Info or Product Info areas. There are two records defined in the MultiRecord area.

Example FRU Information Layout

| Area | Offset | Value | Comments |
|-----------------|--------|-------|---------------------------------|
| Common Header | 0 | 0 | MultiRecord Area Offset |
| | 1 | 0 | |
| | 2 | 0 | |
| | 3 | 0 | |
| | 4 | 0 | |
| | 5 | 1 | |
| | 6 | 0 | |
| Record 1 Header | 7 | 255 | Power Supply Information Record |
| | 8 | 0 | |
| | 9 | 0 | |
| | 10 | 22 | |
| | 11 | 9 | |
| Record 1 Data | 12 | 225 | End of list/Version |
| | 13-25 | X | Record length |
| Record 2 Header | 10 | 9 | Record Checksum |
| | 11 | 9 | Header Checksum |
| | 12 | 225 | Record 1 Data |
| | 26 | 1 | DC Output |
| | 27 | 128 | End of list/Version |
| Record 2 Data | 28 | 13 | Record length |
| | 29 | 54 | Record Checksum |
| | 30 | 60 | Header Checksum |
| Record 2 Data | 31-43 | X | Record 2 Data |

18. Record Field Definitions

The following sections describe the fields for the various types of records that may be present in the MultiRecord Area.

18.1 Power Supply Information (Record Type 0x00)

The following table shows the fields in the Power Supply Information Record.

| Offset | Length | Definition |
|--------|--------|--|
| 0 | 2 | 15:12 – Reserved, write as 0000b 11:0 - Overall capacity (watts) (LSB First) |
| 2 | 2 | Peak VA |
| 4 | 1 | Inrush current |
| 5 | 1 | Inrush interval in ms. |
| 6 | 2 | Low end Input voltage range 1 (10mV, LSB First) |
| 8 | 2 | High end Input voltage range 1 (10mV, LSB First) |
| 10 | 2 | Low end Input voltage range 2 (10mV, LSB First , Zero if single range) |
| 12 | 2 | High end Input voltage range 2 (10mV, LSB First , Zero if single range) |
| 14 | 1 | Low end Input frequency range |
| 15 | 1 | High end Input frequency range |
| 16 | 1 | A/C dropout tolerance in ms |
| 17 | 1 | Binary flags: 7:5 – Reserved, write as 0000b 4:4 – Tachometer pulses per rotation/Predictive fail polarity 3:3 – Hot Swap Support 2:2 – Autoswitch 1:1 - Power factor correction 0:0 - Predictive fail support |
| 18 | 2 | Peak Wattage. 15:12 – Hold up time in seconds 11:0 – Peak capacity (watts) (LSB First) |
| 20 | 3 | Combined Wattage Byte 1: 7:4 – Voltage 1 3:0 – Voltage 2 Byte 2:3 Total Combined Wattage (LSB First) |
| 21 | 1 | Predictive fail tachometer lower threshold (RPS) |

18.1.1 Overall Capacity in Watts

This field allows for Power Supplies with capacities from 0 to 4095 watts.

18.1.2 Peak VA

The highest instantaneous VA value that this supply draws during operation (other than during Inrush). In integer units. FFFFh if not specified.

18.1.3 Inrush

Maximum inrush of current, in Amps, into the power supply. FFh if not specified.

18.1.4 Inrush interval

Number of milliseconds before power supply loading enters non-startup operating range. Set to 0 if no inrush current specified.

18.1.5 Low end Input voltage range 1

This specifies the low end of acceptable voltage into the power supply. The units are 10mV.

18.1.6 High end Input voltage range 1

This specifies the high end of acceptable voltage into the power supply. The units are 10mV.

18.1.7 Low end Input voltage range 2

This specifies the low end of acceptable voltage into the power supply. This field would be used if the power supply did not support autoswitch. Range 1 would define the 110V range, while range 2 would be used for 220V. The units are 10mV.

18.1.8 High end Input voltage range 2

This specifies the high end of acceptable voltage into the power supply. This field would be used if the power supply did not support autoswitch. Range 1 would define the 110V range, while range 2 would be used for 220V. The units are 10mV.

18.1.9 Low end input frequency range

This specifies the low end of acceptable frequency range into the power supply.

18.1.10 High end input frequency range

This specifies the high end of acceptable frequency range into the power supply.

18.1.11 A/C dropout tolerance

Minimum number of milliseconds the power supply can hold up POWERGOOD (and maintain valid DC output) after input power is lost.

18.1.12 Binary flags**18.1.12.1 Tachometer pulses per rotation/Predictive fail polarity**

The power supply can support predictive fail in two ways. The predictive fail pin could be a pass/fail signal or the tachometer output of the power supply fan. This field has a dual meaning depending on what the power supply supports. See section 18.1.15 and 18.1.12.2 for more information.

Tachometer predictive fail signal:

- 0 – One pulse per rotation
- 1 – Two pulses per rotation

Pass/fail predictive fail signal:

- 0 – The signal asserted (1) indicates failure
- 1 – The signal de-asserted (0) indicates failure.

18.1.12.2 Other Binary flags

For each of the following binary flags 0=No, 1=Yes.

- Hot Swap supported
- Autoswitch supported
- Power factor correction supported
- Predictive fail pin supported

18.1.13 Peak Wattage

The high 4 bits indicates the number of seconds peak wattage can be sustained (0-15 seconds). The lower 12 bits indicate the peak wattage the power supply can produce during this time period (0-4095 watts).

18.1.14 Combined Wattage

This field indicates the combined maximum wattage of two voltages. A value of 0 for the combined voltage field indicates there are no combined voltages for a power supply. The combined voltage field can contain the following values:

| | |
|-----------|------|
| 0000b (0) | 12V |
| 0001b (1) | -12V |
| 0010b (2) | 5V |
| 0011b (3) | 3.3V |

For example:

0x00 0x00 0x00 – No combined voltages for the power supply

0x23 0x78 0x00 – 5V and 3.3V have a combined wattage of 120 watts.

18.1.15 Predictive fail tachometer lower threshold

This field serves two purposes. It clarifies what type of predictive fail the power supply supports (pass/fail signal or the tachometer output of the power supply fan) and indicates the predictive failing point for tach outputs. This field should be written as zero and ignored if the predictive failure pin of the power supply is not supported.

| | |
|-------------|--|
| 0x00 | Predictive fail pin indicates pass/fail |
| 0x01 – 0xFF | Lower threshold to indicate predictive failure (Rotations per second). |

This allows the threshold to be set between 60 and 15300 RPMs. Note the threshold is given in rotations per second. Most fans will output two pulses per rotation. For these fans the pulses will need to be divided by two to determine rotations. See section 18.1.12.1 for more information.

| Predictive fail supported | Threshold | Pulses per Rotation / Signal polarity | Notes |
|---------------------------|-----------|---------------------------------------|--|
| 0 | X | X | Predictive fail not supported |
| 1 | 0x00 | 0 | Pass/Fail predictive fail pin (1 = fail) |
| 1 | 0x00 | 1 | Pass/Fail predictive fail pin (0 = fail) |
| 1 | 0x01-0xFF | 0 | Tach output, one pulse per rotation |
| 1 | 0x01-0xFF | 1 | Tach output, two pulses per rotation |

18.2 DC Output (Record Type 0x01)

This record is used to describe the characteristics of a power supplies output voltage. The following table shows the fields in the DC Output Information Record. All two byte values are stored LSB first.

| Offset | Length | Description |
|--------|--------|---|
| 0 | 1 | Output information 7:7 – Standby 6:4 – Reserved, write as 000b 3:0 – Output number |
| 1 | 2 | Nominal voltage (10 mV) |
| 3 | 2 | Maximum negative voltage deviation (10 mV) |
| 5 | 2 | Maximum positive voltage deviation (10 mV) |
| 7 | 2 | Ripple and Noise pk-pk 10Hz to 30 MHz (mV) |
| 9 | 2 | Minimum current draw (mA) |
| 11 | 2 | Maximum current draw (mA) |

18.2.1 Output Information

Bit 7 indicates if the power supply provides this output even when the power supply is switched off. The lower nibble is used to indicate which output is being specified. A power supply may provide the same current on different outputs. A value of zero indicates the output number is unknown.

18.2.2 Nominal voltage

Expected voltage from the power supply. Value is a signed short given in 10 millivolt increments. The following table gives some example values.

| Voltage | Decimal Value | Hex Value |
|---------|---------------|-----------|
| +3.30V | 330 | 0x014A |
| +12.00V | 1200 | 0x04B0 |
| -12.00V | -1200 | 0xFB50 |

18.2.3 Maximum negative voltage deviation

Lowest rated voltage from the power output. Value is a signed short given in 10 millivolt increments.

18.2.4 Maximum positive voltage deviation

Highest rated voltage from the power output. Value is a signed short given in 10 millivolt increments.

18.2.5 Ripple and Noise pk-pk, 10Hz to 30MHz

Value given in mV. Voltage deviation below 10Hz is considered part of the Maximum negative and Maximum Positive voltage deviation specifications.

18.2.6 Minimum current draw

Minimum output capabilities provided for this output. The value is given in milliamps.

18.2.7 Maximum current draw

Maximum output capabilities provided for this output. The value is given in milliamps.

18.3 DC Load (Record Type 0x02)

This record is used to describe the maximum load that a device requires from a particular DC Output. The DC Load records are normally kept on a system board, or a power supply distribution board. The DC Load can be used to see if a power supply, or set of power supplies, can supply appropriate voltage and current for the system. The following table shows the fields in the DC Load Record.

| Offset | Length | Description |
|--------|--------|---|
| 0 | 1 | Voltage required 7:4 – Reserved, write as 0000b 3:0 – Output number |
| 1 | 2 | Nominal voltage (10 mV) |
| 3 | 2 | Spec'd minimum voltage (10 mV) |
| 5 | 2 | Spec'd maximum voltage (10 mV) |
| 7 | 2 | Spec'd Ripple and Noise pk-pk 10Hz to 30 MHz (mV) |
| 9 | 2 | Minimum current load (mA) |
| 11 | 2 | Maximum current load (mA) |

18.3.1 Output Information

The lower nibble is used to indicate which output is being used. A value of zero indicates unknown output.

18.3.2 Nominal voltage

Expected voltage from the power supply. Value is a signed short given in 10 millivolt increments.

18.3.3 Spec'd minimum voltage

Lowest tolerable voltage from the power supply. Value is a signed short given in 10 millivolt increments.

18.3.4 Spec'd maximum voltage

Highest tolerable voltage from the power supply. Value is a signed short given in 10 millivolt increments.

18.3.5 Ripple and Noise pk-pk 10Hz to 30MHz

Value given in mV.

18.3.6 Minimum current load

Minimum output load needed for this output to maintain specified regulation. The value is given in milliamps.

18.3.7 Maximum current load

Maximum output load needed from this for this output to maintain specified regulation. The value is given in milliamps.

18.4 Management Access Record (Record Type 0x03)

The manageable elements of a system may not all be accessible via the same in-band or out-of-band management path. The Management Access Records can be used to hold information that allows software that has access to one system to retrieve information that allows it to get to associated, managed components of the system - and vice-versa. In addition, a system may have more than one management entry point. These records can also be used to determine alternate management access paths as well.

Currently defined Record Types are listed in the table below. All are optional, although the Management URL is expected be valuable in many system implementations.

Typically, a given FRU device will contain *either* the System information *or* the Component information. The distinction is made for systems with more than one management entry point.

| ID | Sub-Record Type | Format | Size | Description |
|------|--------------------------|--------|--------|---|
| 0x01 | System Management URL | String | 16-256 | The Internet Uniform Resource Locator string that can be used through a World Wide Web browser to obtain management information about the system that contains this FRU. (e.g. "http://finance.sc.hp.com:280") |
| 0x02 | System Name | String | 8-64 | A name to identify the system that contains this FRU. (same as DMI "DMTF General Information 001 - System Name") |
| 0x03 | System Ping Address | String | 8-64 | The IP network address of the system that contains this FRU. Can be either the IP address or the host name + domain name (eg. finance.sc.hp.com). |
| 0x04 | Component Management URL | String | 16-256 | The Internet Uniform Resource Locator string that can be used through a World Wide Web browser to obtain management information about this FRU. (same as DMI "DMTF Field Replaceable Unit 002 - FRU Internet Uniform Resource Locator") |

| | | | | |
|------|------------------------|--------|-------|---|
| 0x05 | Component Name | String | 8-256 | A clear description of this FRU. (same as DMI "DMTF Field Replaceable Unit 002 - Description") |
| 0x06 | Component Ping Address | String | 8-64 | The IP network address of this FRU. Can be either the IP address or the host name + domain name (e.g. critter.sc.hp.com). |
| 0x07 | System Unique ID | Binary | 16 | This is a copy of the system GUID from SMBIOS. |

18.4.1 Example

The example below illustrates how the Management URL could be used.

Assume both the Server and the UPS are web-manageable devices with the following management home pages:

Server ("Finance Server 2") – http://finance.sc.hp.com:280
 UPS ("Finance UPS") – http://192.168.0.1

The Server's management pages should include links to attached web-manageable devices such as the UPS. The UPS pages could also include a link back to the Server. ICMB provides a standard interface to the URLs of attached components via the FRU MultiRecord Area. An agent on the Server can then collect all URLs of attached web-manageable devices using IPMI; likewise, the UPS's management processor can determine the Server's URL using ICMB.

Using the data in the MultiRecord Areas (see below), the following HTML tags can be created programmatically:

```
<A HREF= http://finance.sc.hp.com:280>Finance Server 2</A>
<A HREF= http://192.168.0.1>Finance UPS</A>
```

The following tables present examples of records for a system and a UPS.

Example access records for a System:

| field | Contents |
|---------------------------------|--------------------------------|
| Record Type ID | 0x03 = Management Access |
| 7:7 – End of list | 0x02 |
| 6:4 – Reserved, write as 000b | |
| 3:0 – Record Format version | |
| Record Length | 0x1D |
| Record Checksum (zero checksum) | [Checksum] |
| Header Checksum (zero checksum) | [Checksum] |
| Sub-Record Type | 0x01 = System Mgmt. URL |
| Record [28 bytes] | "http://finance.sc.hp.com:280" |
| Record Type ID | 0x03 = Management Access |
| 7:7 – End of list | 0x02 |
| 6:4 – Reserved, write as 000b | |
| 3:0 – Record Format version | |
| Record Length | 0x11 |
| Record Checksum (zero checksum) | [Checksum] |
| Header Checksum (zero checksum) | [Checksum] |
| Sub-Record Type | 0x02 = System Name |
| Record [16 bytes] | "Finance Server 2" |

Example of records for an associated UPS:

| field | Contents |
|---|---|
| Record Type ID | 0x03 = Management Access |
| 7:7 – End of list 6:4 – Reserved, write as 000b 3:0 – Record Format version | 0x02 |
| Record Length | 0x13 |
| Record Checksum (zero checksum) | [Checksum] |
| Header Checksum (zero checksum) | [Checksum] |
| Sub-Record Type | 0x01 = System Mgmt. URL |
| Record [18 bytes] | "http://192.168.0.1" |
| Record Type ID | 0x03 = Management Access |
| 7:7 – End of list 6:4 – Reserved, write as 000b 3:0 – Record Format version | 0x82 (note the 'end-of-list' bit is only set for the last record in the MultiRecord area) |
| Record Length | 0x0C |
| Record Checksum (zero checksum) | [Checksum] |
| Header Checksum (zero checksum) | [Checksum] |
| Sub-Record Type | 0x02 = System Name |
| Record [11 bytes] | "Finance UPS" |

18.5 Base Compatibility Record

This record was originally defined to provide a mechanism for indicating whether particular power supplies are compatible with one another, but this does not preclude its use for indicating compatibility between other entities. Compatibility is not defined in this specification, but is defined by the manufacturer, standards body, or other group specified by the Manufacturer ID field in the record. The Base Compatibility Record may be accompanied by an Extended Compatibility Record.

The general use of the Base and Extended Compatibility records is as follows. The Base Compatibility Record should typically be used to specify a ‘generic’ level of compatibility. For example, suppose a defining body ‘GroupX’ created a specification for interoperability among a class of power supplies. Several different power supply vendors could be required to include a Base Compatibility record with GroupX’s Manufacture ID and compatibility codes as a way of indicating conformance to the GroupX specification. A system vendor ‘MakerY’ may want to have specially branded or approved ‘GroupX compatible’ supplies. The system vendor could ask the power supply vendor to include an Extended Compatibility Record where the Manufacture ID is set to ‘MakerY’. They would then be able to identify the supplies as ‘MakerY’ qualified ‘GroupX’ compatible supplies.

The compatibility records enable automated actions to be taken based on whether the records match and to what degree. For example, one system vendor may require that both the Base and Extended records have particular values in order to power up the system, while another may allow any supply that is ‘Base’ compatible.

| Offset | Length | Definition |
|--------|--------|--|
| 0 | 3 | Manufacturer ID. 3-byte Manufacturer ID field, as specified in the <i>Get Device ID</i> command in the IPMI v1.0 specification. This field identifies the vendor or group that has defined the specific compatibility meaning for the compatibility codes. |
| 3 | 1 | Entity ID code. This designates the type of entity for which compatibility is being specified. E.g. the Entity ID for a power supply is 10 (decimal). The codes are defined in the <i>Entity ID Codes</i> table in the IPMI v1.0 specification. |
| 4 | 1 | Compatibility base. The party identified by the Manufacturer ID specifies this number. This value will typically be used to identify a base compatibility specification. Entities that do not have matching compatibility base values should be considered incompatible |
| 5 | 1 | Code start. This 7-bit value indicates the starting code for a range of compatible codes within a given compatibility set. 7 reserved. Write a 0b. 6:0 Compatibility code start value. 00h and 7Fh are reserved. |
| 6 | 1 | Code range mask. This field provides a mechanism that can indicate ranges of included or excluded code values, starting from the compatibility code start value. See example in section 18.6.1, below. There is no explicit value that indicates the end of the code mask fields. Software must use the record length to determine the end of the code mask fields. The record can be padded with 00h values if it is desired to make the overall record align to a non-byte boundary. 7 1 = Code start + 8 included 6 1 = Code start + 7 included 5 1 = Code start + 6 included 4 1 = Code start + 5 included 3 1 = Code start + 4 included 2 1 = Code start + 3 included 1 1 = Code start + 2 included 0 1 = Code start + 1 included |

| Offset | Length | Definition |
|--------|--------|--|
| 7:N | - | Additional compatibility code range mask fields. These fields are optional and may not be present. The offsets from the Code Start value pick up where the last code range mask field left off. E.g. bit 0 for byte 7 would correspond to Code Start + 9. 7 1 = last byte |

18.6 Extended Compatibility Record

This record is primarily defined to provide a mechanism for indicating whether particular power supplies are compatible with one another, based on additional criteria beyond what was used for the base compatibility record. The Extended Compatibility Record is optional, but if present will typically be accompanied by a Base Compatibility Record. (Note that having the Extended Compatibility Record accompanied by a Base Compatibility is not mandatory per this specification – but may be mandatory per other specifications).

Note that there should be only one base compatibility record, but there may be multiple extended compatibility records.

| Offset | Length | Definition |
|--------|--------|--|
| 0 | 3 | Manufacturer ID. 3-byte Manufacturer ID field, as specified in the <i>Get Device ID</i> command in the IPMI v1.0 specification. This field identifies the vendor or group that has defined the specific compatibility meaning for the compatibility codes. |
| 3 | 1 | Entity ID code. This designates the type of entity for which compatibility is being specified. E.g. the Entity ID for a power supply is 10 (decimal). The codes are defined in the <i>Entity ID Codes</i> table in the IPMI v1.0 specification. This Entity ID code should typically match the value used for Base Compatibility Record. |
| 4 | 1 | Compatibility base. The party identified by the Manufacturer ID specifies this number. This value will typically be used to identify a base compatibility specification. Entities that do not have a matching compatibility base values should be considered incompatible |
| 5 | 1 | Code start. This 7-bit value indicates the starting code for a range of compatible codes within a given compatibility set. 7 reserved. Write a 0b. 6:0 Compatibility code start value. 00h and 7Fh are reserved. |
| 6 | 1 | Code range mask. This field provides a mechanism that can indicate ranges of included or excluded code values, starting from the compatibility code start value. See example in section 18.6.1, below. There is no explicit value that indicates the end of the code mask fields. Software must use the record length to determine the end of the code mask fields. The record can be padded with 00h values if it is desired to make the overall record align to a non-byte boundary. 7 1 = Code start + 8 included 6 1 = Code start + 7 included 5 1 = Code start + 6 included 4 1 = Code start + 5 included 3 1 = Code start + 4 included 2 1 = Code start + 3 included 1 1 = Code start + 2 included 0 1 = Code start + 1 included |
| 7:N | - | Additional compatibility code range mask fields. These fields are optional and may not be present. The offsets from the Code Start value pick up where the last code range mask field left off. E.g. bit 0 for byte 7 would correspond to Code Start + 9. |

18.6.1 Code Range Mask Fields Usage Example

The method of encoding the code ranges using bit masks was selected based on the observation that it is unusual for long stretches of functional revisions to occur without compatibility being broken. It is also based on the observation that it is not unusual to discover that all revisions are not equal, and that sometimes a revision is backward compatible with some earlier revisions, but not all. The mechanism also seeks to reduce the storage requirements for the compatibility records.

For this example, assume that the following code values are compatible: 10, 11, 12, 13, 14, 15, 16, 22, and 23. The Code Start value would be set to 10, and the first Code Range Mask would be set to 00111111b which decodes as:

| | | |
|---|-------------------------|---------------------------------|
| 7 | 0 = Code start (10) + 8 | (= code 18) <i>not included</i> |
| 6 | 0 = Code start (10) + 7 | (= code 17) <i>not included</i> |
| 5 | 1 = Code start (10) + 6 | (= code 16) <i>included</i> |
| 4 | 1 = Code start (10) + 5 | (= code 15) <i>included</i> |
| 3 | 1 = Code start (10) + 4 | (= code 14) <i>included</i> |
| 2 | 1 = Code start (10) + 3 | (= code 13) <i>included</i> |
| 1 | 1 = Code start (10) + 2 | (= code 12) <i>included</i> |
| 0 | 1 = Code start (10) + 1 | (= code 11) <i>included</i> |

Note that this first byte only takes us up to code 18. A second byte is required to indicate compatibility with codes 22 and 23. This byte is set to 00001000b, which decodes as:

| | | |
|---|--------------------------|---------------------------------|
| 7 | 0 = Code start (10) + 16 | (= code 26) <i>not included</i> |
| 6 | 0 = Code start (10) + 15 | (= code 25) <i>not included</i> |
| 5 | 0 = Code start (10) + 14 | (= code 24) <i>not included</i> |
| 4 | 1 = Code start (10) + 13 | (= code 23) <i>included</i> |
| 3 | 1 = Code start (10) + 12 | (= code 22) <i>included</i> |
| 2 | 0 = Code start (10) + 11 | (= code 21) <i>not included</i> |
| 1 | 0 = Code start (10) + 10 | (= code 20) <i>not included</i> |
| 0 | 0 = Code start (10) + 9 | (= code 19) <i>not included</i> |

Thus, we find that using this method, we can encode up to 16 successive revisions using two bytes, while also allowing random revisions among those 16 to be included or excluded from the set of compatible codes.

18.7 OEM Record

OEM Records have one pre-defined data field: a 3-byte Manufacturer ID field, as specified in the *Get Device ID* command in the IPMI v1.0 specification. This occupies the first 3 bytes of the data portion of the record. Subsequent fields within the record are defined by the given OEM.

| Offset | Length | Description |
|--------|--------|--|
| 0 | 3 | Manufacturer ID. LS Byte first. |
| 1:N | N | OEM data, as specified by the party identified by the Manufacturer ID field. |

LAST PAGE